

BLV60L00 2409407AU Ver1

# TABLE OF CONTENTS

Blower/Blower Vacuum Bare Tool .....	3
--------------------------------------	---



## Blower/Blower Vacuum Bare Tool

<b>Ref Number</b>	<b>Part Number</b>	<b>Part Description</b>	<b>Context Notes</b>	<b>Quantity</b>
1	R0105146-00	Suction Pipe Assembly		1
2	R0102435-00	Wheel Assembly		1
3	R0105147-00	Cloth Bag Assembly		1
4	R0105148-00	Blow Pipe Assembly		1
5	R0106166-00	FAN		1
6	R0205877-00	Blade		1
7	R0106167-00	Nut Cap		1